

Yamaha Wolverine Front Skid Plate

Extreme Metal Products # 12970

Hardware:

(5) 5/16" Floor Board Screws

Tools:

RT40 Torx Socket

Ratchet

9/32" drill bit

Drill

Front Skid Plate Installation

(See Picture #1):

- 1.) Remove factory skid plate and discard
- 2.) Drill out the five mounting holes using a 9/32" drill bit
- 3.) Using the supplied 5/16" floor board screws, attach the skid plate



EXTREME
METAL PRODUCTS